



## **DOUBLE SERVICE MANIFOLD**

NOT TO SCALE

NOTES:

1. USE CORPORATION STOP CONNECTION. SEE DETAIL 701.
2. FOR 5/8" x 3/4" METER SETTERS, MANIFOLD LENGTH BETWEEN SETTERS SHALL BE 18".  
FOR 1" METER SETTERS, MANIFOLD LENGTH BETWEEN SETTERS SHALL BE 24".
3. FOR 5/8" x 3/4" METER SETTERS, MANIFOLD SIZE SHALL BE 3/4" FROM BUSHING AT TEE.  
FOR 1" METER SETTERS, MANIFOLD SIZE SHALL BE 1" FROM BUSHING AT TEE.
4. FOR 5/8" x 3/4" METER SETTERS, USE 1-17" x 30" METER BOX AS SHOWN.  
FOR 1" METER SETTERS, USE INDIVIDUAL METER BOXES SIMILAR TO THE SINGLE SERVICE DETAIL 703.
5. THE METER BOX SHALL BE CENTERED OVER THE METER SETTER ASSEMBLY AS SHOWN.

APPROVED: WILLIAM J. CAMPBELL

REV. DATE: JULY 01, 2007

WATER/WASTEWATER DIVISION



STANDARD DETAILS

### **DOUBLE SERVICE MANIFOLD**

FILE | SD703A.DGN | DRAWING NO. **703A**